



ЦЕПЬ	A1-D1, A1-D7	A2-D1, A2-D7	A1-D8, A1-D9	A2-D8, A2-D9	D32, D23, D24	D33	A1-D3, A1-D4, A1-D18, A1-D19, D26, D27, D30, D36	A2-D3, A2-D4, A2-D18, A2-D19, D28, D29, D31, D37, D44	A1-D11, A1-D12, A1-D13, A1-D16, A1-D17, D25, D35, D39, D40, D42, D43	A2-D11, A2-D12, A2-D13, A2-D16, A2-D17, D35, D39, D40, D42, D43
B1	40		-24		20		16		14	
B2		40		24		20		16		14
C	20	20	12	12	10	10	8	8	7	7